



Reducing Coupling




Part No	Pipe Size		Dimensions		
	P-PT, NPT	P1-PT, NPT	A	E	F
SRCN-04-02	1/4	1/8	31.0	8.6	9/16
SRCN-06-04	3/8	1/4	35.1	11.4	11/16
SRCN-08-02	1/2	1/8	39.6	8.6	1 1/16
SRCN-08-04	1/2	1/4	44.5	11.4	1 1/16
SRCN-08-06	1/2	3/8	45.2	15.0	1 1/16
SRCN-12-04	3/4	1/4	46	11.4	1 5/16
SRCN-12-08	3/4	1/2	52.3	18.5	1 5/16
SRCN-16-08	1	1/2	55.6	18.5	1 5/8
SRCN-16-12	1	3/4	57.2	23.9	1 5/8

Adapter



Part No	Pipe Size	Dimensions		
	P-PT, NPT	A	E	F
SA-02	1/8	27.9	4.8	9/16
SA-04	1/4	35.6	7.1	3/4
SA-06	3/8	38.4	9.6	7/8
SA-08	1/2	49.3	11.9	1 1/16
SA-12	3/4	51.3	15.7	1 5/16
SA-16	1	57.9	22.1	1 5/8

Reducing Adapter



Part No	Pipe Size		Dimensions		
	P-PT, NPT	P1-PT, NPT	A	E	F
SRA-02-01	1/8	1/16	27.7	3.0	9/16
SRA-04-02	1/4	1/8	31.0	5.0	3/4
SRA-06-02	3/8	1/8	33.6	5.0	7/8
SRA-06-04	3/8	1/4	38.0	7.0	7/8
SRA-08-02	1/2	1/8	40.1	4.8	1 1/16
SRA-08-04	1/2	1/4	44.7	7.1	1 1/16
SRA-08-06	1/2	3/8	44.5	9.5	1 1/16
SRA-12-04	3/4	1/4	46.2	7.1	1 5/16
SRA-12-06	3/4	3/8	46.2	9.5	1 5/16
SRA-12-08	3/4	1/2	51.3	11.9	1 5/16
SRA-16-04	1	1/4	49.8	7.1	1 5/8
SRA-16-08	1	1/2	54.9	11.9	1 5/8
SRA-16-12	1	3/4	55.1	15.7	1 5/8